



SHIFTPRODUCTS.COM

BUNK LIGHT ADAPTER KIT INSTALLATION



Determine if your truck has existing bezels on the sleeper or not. If not, you can purchase Stainless bezels from us, as they are not included with the Bunk Light Adapter Kit.

1. Remove your factory incandecent LED housing and use a bezel that will fit our Bunk Light Adapter Kit
2. Peel the film off the Bunk Light plate and screw the Watermelon LED to the plate.
3. Silicone the LED wiring to avoid any moisture and dirt from coming in.
4. Simply insert the Bunk Light Adapter Kit into your stainless bezels until it snaps into place.

(Red = Bright, White=Ground, Black=Dim)